

# Special Information Sheet

## Testifire Warranty Counter



With the launch of Testifire Mk2, the way in which warranty is calculated has changed. The warranty period which is 12 months is now calculated on each Testifire by an internal day counter that starts counting from the first day that the unit is turned on.

**> For Firmware Version 6.5 to 7.3.1**


To access the warranty day counter please turn on your Testifire and navigate to the System Information screen as follows:

**1.** Press the Menu Key.

**Menu Key**



**2.** Select System Info.



**3.** View the System Info. Screen



**4.** Press left green; right green; left green key followed by 'Down' arrow to display the warranty screen

**Left green    Right green**



**Down**

The number in the top right corner indicates how many days of the warranty have lapsed. The example to the right shows 140 days have passed since it was first turned on (W=Warranty).



# Special Information Sheet

## Testifire Warranty Counter

> **For Firmware Version 7.3.2 Onwards**

To access the warranty day counter please turn on your Testifire and navigate to the System Information screen as follows:


1. Press the Menu Key



2. Select System Info.



3. View the Warranty Info Screen. The number of days displayed is the number of days since first powered on.



**NOTE.** Any accidental damage, tampering or water ingestion of any kind will always invalidate Testifire warranty. If the Testifire will not power on. Warranty age can be calculated from the date of manufacture. See SIS19.

> **Further Information**

Should you require any further information, Contact SDi Service at 732-751-9266 or email [service@sdifire.com](mailto:service@sdifire.com)



SDi, LLC  
3535 State Highway 66 Parkway  
100 Building 6 Neptune, NJ  
07753 USA

Tel: 732-751-9266  
[sales@sdifire.com](mailto:sales@sdifire.com)  
[www.sdifire.com](http://www.sdifire.com)

